Model RGCJ-00

Installation Instructions







Installation Instructions

1. Feed lock shackle through the two ends of the chain. Insert lock and chain in the Lock Guard*TM*.
2. Place lock shackle in hole. Top for 2", bottom for 1 ½" lock shackle. Lock.
Note: To minimize chance of water accumulation or freezing, place Lock GuardTM upright after locking chain.

Instructivo de instalación

1. Introduzca el grillete del candado a través de los dos extremos de la cadena. Inserte el candado y la cadena al Lock Guard*TM*.
2. Coloque el grillete del candado en el orificio superior para el candado de 2 pulgadas, en el orificio inferior para el candado de 1½ pulgadas. Cierre.

Nota: Para evitar al máximo la posibilidad de que el agua se acumule o congele, coloque el Lock GuardTM en posición vertical tras cerrar la cadena.

Instructions d'installation

1. Faire passer l'anse du cadenzas par les deux bouts de la chaîne. Insérer cadenas et chaîne dans le Lock GuardTM.
2. Placer l'anse dans le trou du haut pour le cadenas de 2 pouces, dans le trou du bas pour le cadenas de 1,5 pouces. Verrouille.

N.B.: Afin de minimiser le risque d'accumulation ou du gel d'eau, mettre le Lock GuardTM à la verticale après le verrouillage de la chaîne.



SGM Enterprises, LLC • Greenville, SC • 866-988-LOCK • www.rangerlock.com

Patented, manufactured to exclusive Ranger Lock specifications in China for SGM Enterprises, LLC.